


DCNF用ショートパーツリスト



パーツリスト
 ウェーバーDCNF用ショートパーツ

番号	必要 個数	品名	部品番号	番号	必要 個数	品名	部品番号
1	1	Carburetor Top Cover	31716.082	41	2	Bearing Cover	58000.017
2	4	Stud	64955.007	42	2	Spacer Bushing	12750.053
3	1	Top Cover Gasket	41705.029	43	2	Spring Washer	55530.010
4	1	Choke Control Rod	61280.056	44	1	Throttle Return Spring	47610.078
5	1	Split Pin	32610.005	45	1	Throttle Control Lever	45041.049
6	1	Float Pin	52000.010	46	2	Idle Mixture Screw	64755.007
7	1	Screw	64700.012	47	2	Idle Mixture Screw Spring	47600.007
8	1	Needle Valve 'O' Ring	83102.070	48	1	Throttle Stop Screw Spring	47600.007
9	1	Bushing	12775.010	49	1	Bushing	12785.084
10	1	Needle Valve	79503.*	50	1	Throttle Stop Screw	64625.012
11	2	Air Corrector Jet	77501.*	51	1	Starter Cover .Including	32556.017
12	1	Choke Control Lever	45096.020	52	1	-Choke Control Spindle	10085.009
13	1	Lever	Not Serviced	53	1	-Cover	32556.016
14	1	Screw	64615.004	54	1	-Return Spring	47610.043
15	1	Pump Demand Valve	79706.050	55	1	-Choke Lever	45025.089
16	2	Emulsion Tube	61450.*	56	1	-Spring Washer	55525.010
17	1	Float	41015.015	57	1	-Nut	34715.010
18	1	Pump Cover	32486.041	58	1	Filter Gauze	37000.016
22	1	Pump Jet	76215.*	59	2	Choke Cover Screw	64700.004
23	2	Pump Jet 'O' Ring	41540.014	60	2	Washer	55510.038
24	2	Main Jet	73405.*	61	2	Main Venturi (Choke Tube)	72129.*
25	2	Idle Jet	74405.*	62	2	Auxiliary Venturi	71107.*
26	2	Idle Jet 'O' Ring	41565.002	63	2	Starter Jet	75605.*
27	2	Idle Jet Holder	52570.006	64	2	Starter Valve Piston	64330.008
28	1	Pump Spring	47600.107	65	2	Starter Valve Spring	47600.139
29	1	Pump Diaphragm	47407.261	66	2	Spring Guide	12775.024
30	4	Pump Cover Screw	64700.006	67	2	Spring Clip	10140.002
31	2	Throttle Spindle Nut	34710.003	68	1	Fuel Filter Inspection Cover	61002.010
32	2	Lock Washer	55520.004	69	1	Fuel Filter Cover Gasket	41530.024
33	1	Spacer	12750.032	70	1	Filter Washer	61060.001
34	1	Pump Cam	14852.011	71	1	Fuel Filter	37020.002
36	1	Throttle Shaft	10005.211	72	4	Washer	55510.034
37	2	Throttle Valve	64005.020	73	4	Top Cover Screw	64700.005
38	4	Throttle Valve Screw	64520.027	74	2	Air By-Pass Screw	64750.002
40	2	Sealed Bearing	32650.003	75	2	Air By-Pass Screw Locking Nut	34705.001

*が記された部品は、サイズで区分するための3桁の数字が入ります。